

# QUICK ATTACH™ WEDGE KIT



**ITEM**

**A**

**WT**

(wire size)

(lb)

P0760-W003-C

1/8"

0.03

P0760-W004-C

5/32"

0.03

P0760-W005-C

3/16"

0.04

P0760-W007-C

1/4"

0.05

P0760-W009-C

5/16"

0.08

P0760-W010-C

3/8"

0.11

P0760-W013-C

1/2"

0.13

**NOTE:**

**NOW YOU CAN REUSE YOUR QUICK ATTACH™ TURNBUCKLES AND HARDWARE WITH THIS LOW COST REPLACEMENT WEDGE KIT. IT FEATURES A BRONZE WASHER, 3-PART WEDGE AND WEDGE BAND. FOR USE WITH ALL SUNCOR QUICK ATTACH™ FITTINGS. WORKING LOAD LIMIT OF QUICK ATTACH™ FITTINGS ARE 75% OF THE WLL OF WIRE USED.**